



For ultimate dependability, the Aqua ABW-S boasts IP68 washdown protection, meaning it's suitable for weighing messy or dusty materials in demanding environments. In addition to the easy-to-clean grade 304 stainless steel housing and platform, the pan is removable for hygienic maintenance. Overload protection helps safeguard the scale against accidental overloads for a reliable, long-lasting weighing solution. Well-suited for food processing, batching and packaging, the Aqua offers features designed to improve productivity. The bright LED displays clearly show results in the front and rear of the scale, allowing multiple users to use the same scale, while hidden colour-changing indicators light up during checkweighing to show if results are over, under or within preset limits. Percentage weighing makes baking and recipe batching effortless, while parts counting speeds up packaging tasks. Take advantage of the internal rechargeable battery for operation anywhere, including areas where access to power is limited. The Aqua's quick stabilisation time means weighing tasks are faster and more efficient.

Complete protection whatever the application. With grade 304 stainless steel, this IP68 bench scale looks the part.



Checkweighing Function Indicators



Features

- IP68-rated for protection against water and dust
- Grade 304 stainless steel casing for a premium, professional look, easy cleaning and ultimate durability
- Sealed keypad protects against dirt and spills
- Clear, hidden-until-needed function indicators keep focus where it's needed
- Heavy-duty rubber feet for stability when weighing
- Front and rear 20mm LED displays allows for dual use
- Bright LED displays front and rear for easy viewing in most environments
- External calibration allows for verification and adjustment with weights
- Overload protection helps prevent damage to internal components
- Auto power-off feature conserves battery life
- Rechargeable battery for operation almost anywhere
- AC adaptor included
- Stabilisation time of within 1 second

Applications

- Weighing
- Checkweighing
- Percentage weighing
- Parts counting



About ADAM:

For nearly 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Product Details

Model	ABW 4S	ABW 8S	ABW 16S	ABW 32S
Capacity	4kg	8kg	16kg	32kg
Readability	0.1g	0.5g	1g	2g
Repeatability	0.2g	1g	2g	5g
Linearity	0.2g	1g	2g	5g
Pan Size	245x180mm			300x210mm
Weighing Units	g, kg, lb, oz, lb:oz			
Stabilization Time (sec.)	1			
Calibration	External			
Display	Dual-display LED with 20mm-high digits			
Power Supply	12VDC 50/60Hz 800mA adapter, Internal rechargeable battery			
Operating Temperature	0° to 40°C			
Battery Life	55 hours			
Housing	Stainless steel top housing with ABS plastic base			
Overall Dimensions	255x290x105mm			300x310x105mm
Net Weight	2.5kg			

Accessories

Item number	Description
3002014371	Hard carrying case
303149759	Vegetable Scoop (complete with fitting to scales)
303149760	Confectionery Scoop (complete with fitting to scales)
700660290	Calibration certificate

Key Accessories



Scoops

Metal scoops are designed to make portioning and food measurement easy. Two sizes available: small and large.



Hard Carrying Case

Allows the Aqua to be placed inside to protect it during transportation. The hard shell case is durable and comes with a lock so that you can secure the scale in the case as needed. Die cut foam insert provides room for the scale, power supply and top pan.

Supplied by:



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.