



# pt range

## Oil Free Air Compressors

low noise, high quality



PT5

Bambi have used our experience of over 40 years manufacturing air compressors to bring you the quiet, oil-free PT range. Compressors are available in a choice of receiver and pump formats to ensure that the one chosen is perfectly adapted to the application. With ultra low noise, from only 52 dB(A) and 100% oil free operation, the PT range delivers a low maintenance solution to ultra-quiet oil free compressed air.

Model								
PT5	L/Min	Ltrs	Bar	Kw HP	Volts/Hz	dB(A)	KG	CM-hxWxd
	128	4	8	0.75 1.0	230/50	62	17	34 x 40 x 33
FAD	1	2	3	4	5	6	7	8
L/Min	97	90	81	75	69	63	56	50

Max Duty Cycle = 65%. 110 volt available on request.

Ideal for Pneumatic Control Systems, Scientific Laboratories, Staple Guns, Picture Framing, Autoclaves, Veterinary Dental Carts, Drink Dispensing, Door Opening, Exhibition Stands – and anywhere low maintenance oil-free air is required.

PT has been designed with quality at the forefront – the elegant motor cover is more than just aesthetically pleasing – it provides user protection from the hotter parts of the compressor while ensuring perfect air circulation for optimum performance.

Model								
PT15	L/Min	Ltrs	Bar	Kw HP	Volts/Hz	dB(A)	KG	CM-hxWxd
	128	15	8	0.75 1.0	230/50	62	23	53 x 37 x 37
FAD	1	2	3	4	5	6	7	8
L/Min	97	90	81	75	69	63	56	50

Max Duty Cycle = 65%. 110 volt available on request.

- Minimal maintenance
- No oil level to check
- Ultra low noise when running
- Compact and ready to use
- Built in Britain



PT15

Anti-corrosion, internally coated receivers are fitted across the range\*, prolonging the life of the receiver and ensuring that the air delivered is contamination free.

All of the PT range runs off a single phase 240v supply and come with a standard 3 pin plug for the UK and Euro plug where requested.



PT24

Model								
PT24	L/Min	Ltrs	Bar	Kw HP	Volts/Hz	dB(A)	KG	CM-hxWxd
	128	24	8	0.75 1.0	230/50	62	25	57 x 40 x 40
FAD	1	2	3	4	5	6	7	8
L/Min	97	90	81	75	69	63	56	50

Max Duty Cycle = 65%. 110 volt available on request.

\*not model PT5



Fitted with a Condor pressure switch, 10 micron air filter & outlet pressure regulator and stainless steel braided pipework as standard, the PT range is built in Bambi's Birmingham factory to ensure that it exceeds your expectations. Our central base is ideal for distribution across the UK, with next day delivery possible on all models.

Model								
PT50	L/Min	Ltrs	Bar	Kw HP	Volts/Hz	dB(A)	KG	CM-hxWxd
	256	50	8	1.5 2.0	230/50	66	44	62 x 88 x 34
FAD	1	2	3	4	5	6	7	8
L/Min	194	180	162	150	138	126	112	100

Max Duty Cycle = 65%. 110 volt available on request.

Fitted with a 10 micron filter regulator, stainless steel braided pipework and a wheel kit included as standard, the PT90 offers a versatile, mobile solution for when you require compressed air in multiple locations.

Model								
PT90	L/Min	Ltrs	Bar	Kw HP	Volts/Hz	dB(A)	KG	CM-hxWxd
	384	90	8	2.25 3.0	230/50	69	85	76 x 104 x 43
FAD	1	2	3	4	5	6	7	8
L/Min	291	270	243	225	207	189	168	150

Max Duty Cycle = 65%. 110 volt available on request.

For an even lower maintenance solution, all of the PT compressors can be fitted with an auto-drain – avoiding the manual draining of condensate in the receiver.



Internally Coated Receiver



10 Micron Outlet Filter and Adjustable Pressure Regulator



Condor Pressure Switch

Every PT compressor is protected by a comprehensive 12 month warranty extending to 5 years on the air receiver.



PTS20

When low noise levels are critical, choose the PTS20. With a running noise level of just 52 dB(A) and compact design, the PTS20 can be located under most work surfaces for a discreet installation.

Like the rest of the “open” PT range, PTS20 oil free compressors are built in the Bambi Ltd factory in Birmingham UK to our exceeding standards of quality.

PTS20 compressors feature glycerine filled gauges, an integrated regulator and quiet extraction fans as standard as well as high flow, quick release couplings, for fast and easy switching of airlines & installation.

Protected by a comprehensive 12 month warranty on parts and workmanship (5 year warranty on the internally coated air receiver), you can buy a Bambi compressor with confidence.



Model								
PTS20	L/Min	Ltrs	Bar	Kw HP	Volts/Hz	dB(A)	KG	CM-hxWxd
	128	21	8	0.75 1.0	230/50	52	57	72 x 54 x 50
FAD	1	2	3	4	5	6	7	8
L/MIN	97	90	81	75	69	63	56	50

Max Duty Cycle = 65%



Bambi Air Ltd was established in 1977 and enjoys a worldwide reputation for quality and after-sales care and service. Dedicated to the manufacture of innovative and meticulously engineered products, our extensive range is as diverse as our customers themselves.

Our policy of continual development and improvement has ensured we remain at the forefront of our industry. Through acquisition and organic growth we now operate a number of specialist divisions within our organisation, each committed to the very highest standards of customer satisfaction.



- Budget Silent Running Air Compressors
- Medical/Dental Silent Air Compressors
- Oil Free Air Compressors
- Diaphragm Compressors & Vacuum Pumps
- Gas Circulators
- Sprinkler System Compressors

Our spray painting division manufactures -



- HVLP Turbine Sprayers
- Multi Fleck Paint Sprayers



# WolfLabs

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

**[www.wolflabs.co.uk](http://www.wolflabs.co.uk)**

**Tel : 01759 301142**

**Fax : 01759 301143**

**[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)**

Please contact us if this literature doesn't answer all your questions.