

## NUGGET ICE MAKER, MODULAR FM-1200ALKE-R452N

Product series: FM

Item number: F073-C207



This modular ice maker produces flake ice, which is often used for produce display of fish, fresh food and bottled beverages. In the medical field, flake ice is also used for organ transportation. Utilizing the most efficient ice making process due to the unique auger system, the water consumption is equal to the ice production. The main characteristic of Hoshizaki's flake ice is that 'freeze-burn' is prevented when displaying fresh fish or produce. This model has a stainless steel bottom and is configured with our storage bins.

- Efficient ice making process due to Hoshizaki's unique FM auger system.
- Utilises all water brought into the machine; therefore water consumption is equal to ice production.
- Auger is made of double hardened stainless steel. Combined with carbon bearings, they work optimally in a tough and wet environment. Benefits include: longer product life expectancy and reduced maintenance costs.
- Hoshizaki ice makers are micro computer controlled, controlling the ice making process to perform at its best under varying circumstances, without having to make physical adjustments.
- Quality stainless steel auger and evaporator increase the life expectancy of these components and the whole ice maker, as well as reducing costly maintenance visits.
- An easily cleanable air filter allows end users to carry out a routine cleaning schedule, extending product life expectancy and reducing the frequency and costs of maintenance call-outs.

### SPECIFICATIONS

|                                             |                           |
|---------------------------------------------|---------------------------|
| <b>Product title</b>                        | Nugget Ice Maker, Modular |
| <b>Production capacity (kg/24h) approx.</b> | 1060                      |
| <b>Electric connection</b>                  | 1/220 - 240V/50Hz         |
| <b>Electric connection Load (kW)</b>        | 0.515                     |
| <b>Outside Dimensions W x D x H (mm)</b>    | 762 x 700 x 780           |
| <b>Ice type</b>                             | Flake                     |

|                                 |                  |
|---------------------------------|------------------|
| <b>Refrigerant</b>              | R452             |
| <b>Cooling system</b>           | Remote Condenser |
| <b>Product configuration</b>    | Modular          |
| <b>Net weight (kg)</b>          | 98               |
| <b>Gross Weight Packed (kg)</b> | 108              |
| <b>Corresponding bin(s)</b>     | B210SA, B340SA   |



# WolfLabs

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

**[www.wolflabs.co.uk](http://www.wolflabs.co.uk)**

**Tel : 01759 301142**

**Fax : 01759 301143**

**[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)**

Please contact us if this literature doesn't answer all your questions.