

HULME MARTIN HEAT SEALERS

HM 1000 P



(Hand Operated, Portable* Heat Sealer) – Part No. 10002061

Maximum Sealing Length	300mm (12")
Seal Width	3mm (Standard)
Film Thickness	2 x 1000 gauge (2 x 250 micron)
Voltage	240V, 110V (Conversion)
Power Consumption (Watts)	315W (per seal)
Fuse Rating	T 3.15 amp
Footprint	241mm (L) x 139mm (W) x 150mm (H)
Weight	7.5 Kg
Operation	Hand Operated
Mounting	Bench Mounted & Portable*
Options	6mm Wide Seal (for thicker materials & laminates), available as a HM 1000 P-TWIN (with upper & lower Jaws heated)

The **HM 1000 P** – Hand Operated, Portable* Heat Sealer

Designed for repetitive seals on large, heavy or irregularly shaped packages, polythene bags, sheeting, pallet covers, etc. whilst providing maximum flexibility of operation.

Powered with a Dual Electronic Timer, for complete control of heating & cooling cycle - so that the settings can be fine-tuned to the material being used.

Robust cast aluminium jaws with lever action for reduced manual effort.

Used for export packaging, protective storage & vacuum packing of humidity sensitive equipment.

A wide range of industrial, warehousing & general packaging applications.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

Must be connected to Mains Power Supply, is NOT battery operated



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.