



HULME MARTIN HEAT SEALERS

HULME MARTIN HEAT SEALERS

HM 1800 CD



(Foot Operated, Medium Capacity Impulse Heat Sealer) – Part No. 18002171

Maximum Sealing Length	490mm (19.5")
Seal Width	3mm (Standard)
Film Thickness	2 x 1000 gauge (2 x 250 micron)
Voltage	240V, 110V (Conversion)
Power Consumption (Watts)	415W (per seal)
Fuse Rating	T 3.15 amp
Footprint	607mm (L) x 190mm (W) x 190mm (H)
Weight	12.5 Kg
Operation	Foot Operated (via Chain & Pedal)
Mounting	Bench Mounted
Options	6mm (Wide Seal), T-Wire (Seal-Cut-Seal), Round Wire (Cut-&-Seal), Stand Kit, Rollers/Brackets & Retainers (for Layflat Tubing)

The **HM 1800 CD (Dual Timer with Cutter)** – Medium Capacity Impulse Heat Sealer

A general-purpose foot operated machine, providing great flexibility of operation. Leave hands free to manipulate large or heavy packages.

Simple bench mounting or optional stand available.

This CD model has a Dual Electronic Timer for complete control of the heating & cooling cycle, with a cutter to facilitate bag production from lay flat tubing.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ
Registered in England No. 5484051 VAT No. GB 864 4792 82



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.