



**HULME MARTIN HEAT SEALERS**

# **HULME MARTIN HEAT SEALERS**



**HM 2500**  
**—E/Standard—**

**(Hand Operated, Standard Impulse Heat Sealer) – Part No. 25001051**

|                                  |                                                                                                               |
|----------------------------------|---------------------------------------------------------------------------------------------------------------|
| <b>Maximum Sealing Length</b>    | 240mm (9.5")                                                                                                  |
| <b>Seal Width</b>                | 3mm (Standard)                                                                                                |
| <b>Film Thickness</b>            | 2 x 1000 gauge (4 x 250 micron)                                                                               |
| <b>Voltage</b>                   | 240V, 110V (Conversion)                                                                                       |
| <b>Power Consumption (Watts)</b> | 165W (per seal)                                                                                               |
| <b>Fuse Rating</b>               | T 3.15 amp                                                                                                    |
| <b>Footprint</b>                 | 338mm (L) x 123mm (W) x 170mm (H)                                                                             |
| <b>Weight</b>                    | 5.1 Kg                                                                                                        |
| <b>Operation</b>                 | Hand Operated                                                                                                 |
| <b>Mounting</b>                  | Bench or Wall Mounted                                                                                         |
| <b>Options</b>                   | T-Wire (Seal-Cut-Seal), Round Wire (Cut-&-Seal), Stand Kit, Rollers/Brackets & Retainers (for Layflat Tubing) |

The **HM 2500 (E/Standard)** – Standard Impulse Heat Sealer

A general purpose bench or wall mounted Standard Impulse Sealer.

Instant seals without warm-up, but capable of high volume production work.

The parallel open ended sealing jaws allow occasional larger bags to be sealed by repositioning the bag along the element.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

**IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS  
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS**  
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ  
Registered in England No. 5484051    VAT No. GB 864 4792 82



# WolfLabs

**Pricing on any accessories shown can be found by keying the part number into the search box on our website.**

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

**[www.wolflabs.co.uk](http://www.wolflabs.co.uk)**

**Tel : 01759 301142**

**Fax : 01759 301143**

**[sales@wolflabs.co.uk](mailto:sales@wolflabs.co.uk)**

Please contact us if this literature doesn't answer all your questions.