



HULME MARTIN HEAT SEALERS

HULME MARTIN HEAT SEALERS



HM 2950
—Stainless Steel—

(Hand Operated, Stainless Steel Impulse Heat Sealer) – Part No. 29502051

Maximum Sealing Length	310mm (12.5")
Seal Width	3mm (Standard)
Film Thickness	2 x 1000 gauge (2 x 250 micron)
Voltage	240V, 110V (Conversion)
Power Consumption (Watts)	300W (per seal)
Fuse Rating	T 3.15 amp
Footprint	347mm (L) x 161mm (W) x 190mm (H)
Weight	7.8 Kg
Operation	Hand Operated
Body Construction	316 Stainless Steel
Mounting	Bench Mounted

The **HM 2950 SS (Stainless Steel)** – Standard Impulse Heat Sealer

The HM 2950 SS has been specifically designed for food, medical & laboratory applications - where hygiene, health & safety criteria require an easily cleaned, moisture resistant and non-corrosive sealer.

This machine has a Dual Timer with a pre-set cooling time.

Constructed from Food Grade 316 Stainless Steel, with a low voltage safety operation and IP rated components.

This machine is used in many hospitals for packing medical samples, & also can be found in many supermarkets in the fresh fish & bakery sections.

The machine comes with a spare Heater Bar Assembly attached to the back of it, to allow continuous production.

It is simple to maintain with consumable spares being easy to fit & available from stock.

**IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS**
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ
Registered in England No. 5484051 VAT No. GB 864 4792 82



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.