



HULME MARTIN HEAT SEALERS

HULME MARTIN HEAT SEALERS

HM3000 CDM



(Hand Operated, Standard Impulse Heat Sealer) – Part No. 30202161

Maximum Sealing Length	310mm (12.5")
Seal Width	3mm (Standard)
Film Thickness	2 x 1000 gauge (2 x 250 micron)
Voltage	240V, 110V (Conversion)
Power Consumption (Watts)	300W (per seal)
Fuse Rating	T 3.15 amp
Footprint	455mm (L) x 139mm (W) x 190mm (H)
Weight	8.5 Kg
Operation	Hand Operated (with Hold Down Magnet)
Mounting	Bench Mounted
Options	Rollers & Brackets (for Layflat Tubing)

The **HM 3000 CDM (Dual Timer with Cutter & Magnet)** – Standard Impulse Heat Sealer

General purpose machines with many applications.

Used extensively by hospitals, laboratories, retailers, engineering & other industries.

This CDM model has a Dual Electronic Timer for complete control of the heating & cooling cycle, with a cutter to facilitate bag production from lay flat tubing.

An extra feature is that it comes with a Hold-Down Magnet, allowing hands-free completion of sealing cycles.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

**IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS**
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ
Registered in England No. 5484051 VAT No. GB 864 4792 82



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.