



HULME MARTIN HEAT SEALERS

HULME MARTIN HEAT SEALERS



HM 7600 CDL

(Foot Pedal & Cable Operated with Cutter, Large Capacity Impulse Heat Sealer)

– Part No. 76002181

Maximum Sealing Length	770mm (30")
Seal Width	3mm (Standard)
Film Thickness	2 x 1000 gauge (2 x 250 micron)
Voltage	240V, 110V (Conversion)
Power Consumption (Watts)	360W (per seal)
Fuse Rating	T 3.15 amp
Footprint	955mm (L) x 180mm (W) x 190mm (H)
Weight	21 Kg
Operation	Foot Operated (via Cable & Pedal)
Mounting	Bench Mounted
Options	Stand Kit, Rollers/Brackets (for Layflat Tubing)

The **HM 7600 CDL (Foot Pedal & Cable Operated with Cutter)** – Large Capacity Impulse Heat Sealer

A large capacity, general purpose foot operated impulse sealing machine.

For industrial, warehousing & mail order applications.

Simple bench mounting or optional stand available.

This CDL model has a Dual Electronic Timer for complete control of the heating & cooling cycle, with a cutter to facilitate bag production from lay flat tubing.

It also has a cable operated foot pedal which allows increased flexibility of installation.

Another advantage is that the foot pedal is of a lever action design which helps to minimise operator effort.

This machine is simple to maintain with consumable spares being easy to fit & available from stock.

**IMPULSE • CONSTANT HEAT SEALERS • VACUUM SEALERS • SHRINK CHAMBERS
SACK SEALERS • BESPOKE SOLUTIONS • SEMI-AUTOMATIC MACHINES • SECURITY SEALERS**
Registered office: Unit 5B Country Business Centre, White Cottage Farm, Lucas Green Road, West End, Woking, Surrey, GU24 9LZ
Registered in England No. 5484051 VAT No. GB 864 4792 82



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.