



The long lasting story of success with dust and spray protected display device



Animal weighing



Recipe-weighing



Piece counting



Features

- Thanks to battery operation/rechargeable battery operation (optional), compact, lightweight construction, it is suitable for the use in several locations
- Display device: Plastics, protection against dust and water splashes IP65, flexible positioning
- Weighing plate stainless steel, painted steel base
- PRE-TARE function for manual subtraction of a known container weight, useful for checking fill-levels
- With the recipe function you can weigh the different ingredients of a mixture. As a check, you can also call up the total weight of all the ingredients
- Freely programmable weighing unit, e.g. display direct in special units such as length of thread g/m, paper weight g/m², or similar
- Protective working cover included with delivery

Technical data

- Large backlit LCD display, digit height 25 mm
- Weighing platform dimensions, stainless steel
 - A** W×D×H 318×308×75 mm
 - B** W×D×H 318×308×88 mm
 - C** W×D×H 522×403×83 mm, see larger picture
 - D** W×D×H 522×406×98 mm
 - E** W×D×H 650×500×89 mm
- Dimensions of display device W×D×H 225×110×55 mm
- Optional battery operation, 9 V block not included in scope of delivery, operating time up to 12 h
- Permissible ambient temperature 5 °C/35 °C

Accessories

- Protective working cover over the display device, scope of delivery: 5 items, KERN DE-A12S05
- Internal rechargeable battery pack, operating time up to 30 h without backlight, charging time approx. 10 h, KERN NDE-A02
- Wall mount for display device, KERN DE-A13
- **2** Stand to elevate display device, Height of stand approx. 480 mm, KERN DE-A10
- Suitable for models with weighing plate size **C**, **D**, **E**: Mount to fasten the display device to the platform, KERN DE-A11N
- Individual header data: the free software SHM-01 can be used to print 4 header lines on the printout when using printer YKN-01
- Further details, plenty of further accessories and suitable printers see *Accessories*

STANDARD



OPTION



Model	Weighing capacity [Max] kg	Readability [d] g	Reproducibility g	Linearity g	Smallest part weight (Normal) g/piece	Cable length approx. m	Net weight approx. kg	Weighing plate	Options
									DAkKS Calibr. Certificate
KERN									DAkKS KERN
Multi-division balance with high resolution readability, with increasing or decreasing load, it switches automatically to the next largest or smallest weighing range [Max] and readout [d].									
DE 15K0.2D	6 15	0,2 0,5	0,2 0,5	± 0,8 2	4	1	4,0	B	963-128
DE 35K0.5D	15 35	0,5 1	0,5 1	± 2 4	10	1	7	B	963-128
DE 60K1D	30 60	1 2	1 2	± 4 8	20	1,47	7	B	963-129
DE 60K1DL	30 60	1 2	1 2	± 4 8	20	1,4	15	D	963-129
DE 150K2D	60 150	2 5	2 5	± 8 20	40	1,6	7	B	963-129
DE 150K2DL	60 150	2 5	2 5	± 8 20	40	1,4	15	D	963-129
DE 300K5DL	150 300	5 10	5 10	± 20 40	100	1,4	15	D	963-129
Multi-division balance without high resolution readability									
DE 6K1D	3 6	1 2	1 2	± 3 6	40	1,4	4,8	A	963-128
DE 15K2D	6 15	2 5	2 5	± 6 15	100	1,4	4,8	A	963-128
DE 35K5D	15 35	5 10	5 10	± 15 30	100	1,4	4,8	A	963-128
DE 35K5DL	15 35	5 10	5 10	± 15 30	100	1,4	16	C	963-128
DE 60K10D	30 60	10 20	10 20	± 30 60	200	1,4	4,8	A	963-129
DE 60K10DL	30 60	10 20	10 20	± 30 60	200	1,4	16	C	963-129
DE 150K20D	60 150	20 50	20 50	± 60 150	400	1,5	5,0	A	963-129
DE 150K20DL	60 150	20 50	20 50	± 60 150	400	1,5	16	C	963-129
DE 150K20DXL	60 150	20 50	20 50	± 60 150	400	1,4	19	E	963-129
DE 300K50DL	150 300	50 100	50 100	± 150 300	2000	1,05	28	E	963-129
DE 300K50D	150 300	50 100	50 100	± 150 300	2000	1,25	16	C	963-129
DE 6K0.5A	6	0,5	0,5	± 1,5	10	1,4	4,8	A	963-128
DE 12K1A	12	1	1	± 3	20	1,4	4,8	A	963-128
DE 24K2A	24	2	2	± 6	40	1,4	4,8	A	963-128
DE 60K5A	60	5	5	± 15	100	1,4	4,8	A	963-129
DE 120K10A	120	10	10	± 30	200	1,4	5,0	A	963-129



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.